


# Server Configuration Lab04

# Contents

Top	ology		
	Shares		
1.1	Creating Shares	4	
1.2	NTFS Quotas	21	
2	Volume Shadow Copy Services (VSS)	24	
	Enable VSS		
	Work Folders		
3.1	Install Work Folders Role	32	
4	Research Topics (Optional)	49	
Refe	erences	49	

# Topology




## 1 Shares

Shares provide centralized management as well as higher data security and protection.

# 1.1 Creating Shares


1. Open the Windows W2K12R2-ADDC server by clicking the icon in the topology. Click "PC > Send CTRL+ALT+DEL".




2. Type P@ssw0rd1 as the administrator password and hit "Enter".




3. From the "Server Manager – Dashboard", click "File and Storage Services".




4. Click on "Shares", right click the open white space under SYSVOL and select "New Share".




5. Click through each of the share profiles and read the descriptions. Select "SMB Share – Quick" and click "Next".




6. On the "Share Location" window, select the "H:" drive and click "Next".




7. On the "Share Name" window, type Human Resources and click "Next".




8. On the "Other Settings" page, click "Next".




9. On the "Permissions" window, select "Customize permissions".




10. Click the "Share" tab, click "Everyone" and click "Remove".




## 11. Stay on the page and click "Add".




12. Click "Select a principal".



13. Type "Human Resources" and click "Check Names". Click "OK".



14. Place a check mark by "Full Control" and click "OK". Click "OK".




## 15. On the "Permissions" page, click "Next".




#### 16. Click "Create" and click "Close".




17. Right click the white space under Human Resources and select "New Share".



18. On the "Select Profile" page, select "SMB Share - Quick" and click "Next".




19. On the "Share Location" page, select the "T:" volume and click "Next".




20. On the "Share Name" page, type IT for the name and click "Next".

Specify share r	ame
Select Profile	Share name:
Share Location	
Share Name	Share description:
Other Settings	
	Local path to share:
	T:\Shares\IT
	1 If the folder does not exist, the folder is created.
	Remote path to share:
	\\W2K12R2-ADDC\\T


#### 21. On the "Other Settings" page, click "Next".




#### 22. On the "Permissions" page, click "Customize permissions".




# 23. Click the Share Tab, click on "Everyone" and click "Remove".




#### 24. Click on "Add".




## 25. Click "Select a principal"




26. Type "IT" and click "Check Names" and click "OK".




27. Place a check by "Full Control" and click "OK".



28. On the "Permissions" page, click "Next". Click "Create".




29. On the "Results" page, click "Close".



30. Open a console to the WIN7 machine by clicking the icon in the topology.



31. Click "PC > Send CTRL+ALT+DEL".




32. Click on "Switch User" and select "Other User".




33. Type mydomain\sallyhr as the username and Password1 as the password. Hit "Enter".




34. Left click the Start Button and type \\w2k12r2-addc\ and hit "Enter".




35. Double click on the Human Resources folder.




36. Click once on "New Folder" in the navigation bar and type **Reports** as the folder name. Hit "Enter".



37. Double click the "Reports" folder to open.




38. Right click any open white are and select "New > Text Document".




39. Name the document "Q1-2014" and hit "Enter".


080



40. Click on w2k12r2-addc in the navigation bar to return to the root share.




41. Double click on "IT" to see the access error. Click "Close".




# 1.2 NTFS Quotas


1. Return to the W2K12R2-ADDC machine. On the "Shares – Dashboard", make sure Human Resources is highlighted and click the link to install the "File Resource Manager".




2. Click "Add Features" to install the required features.




3. On the "Server Roles" page, click "Next".




4. On the "Features" page, click "Next".




5. On the "Confirmation" page, click "Install". Click "Close".



6. Wait a few seconds and click refresh button on the "Shares – Dashboard". Make sure the "Human Resources" share is highlighted in the middle pane. When the link below changes, click the link to open the "Configuration Quota dialog box".



7. Place a check by "Automatically create and apply quotas for all users" click "OK".




# 2 Volume Shadow Copy Services (VSS)


Volume Shadow Copy Services is a technology that allows point-in-time backups of entire volumes.

# 2.1 Enable VSS


1. On the "Server Manager – Dashboard" navigate to "Tools > Computer Management".



2. Right click "Shared Folders" and click "All Tasks > Configure Shadow Copies".



3. In the "Shadow Copies" window, highlight "H:\" and click "Enable".




4. Read the information about high volume I/O and click "Yes".




5. Highlight "H:\" and click "Settings".




6. This is where you input manual settings for the VSS.




7. Click "Schedule" to view the current schedule. Click "Cancel" twice.




8. Open a console to the WIN7 machine, left click the Start Button and left click "Computer".




9. Select "Map network drive" from the navigation bar.




10. Use the drop down to change the drive letter to H:\ and type \\w2k12r2-addc\Human Resources into the Folder box. Click "Finish".




11. The Human Resources folder will automatically open. Close the folder and notice the new network location.




12. Double click on the "Human Resources" network location. Double click on the "Reports" folder. Right click under "Q1-2014" and select "New > Text document".




13. Type Q2-2014 as the file name and hit "Enter".




14. Right click on "Q1-2014" and select "Delete. Click "Yes" to confirm the deletion.



15. Return to the W2K12R2-ADDC server and click on the Shadow Copy that was created. Click "Revert".




16. Read the information about reverting a Shadow Copy, place a check next to "Check here if you want to revert this volume" and click "Revert Now". Click "Ok" and close the "Computer Management" window.



17. Return to the WIN7 machine and refresh the Reports folder.

(Note: Only Q1-2014 returns. Q2-2014 was not part of the original Volume Shadow Copy.)




# 3 Work Folders


Work Folders is a network file sync role. Users are able to work from almost any device in the office or from home and have access to the required documents to perform their job.

## 3.1 Install Work Folders Role


 Return to the W2K12R2-ADDC server. On the "Server Manager – Dashboard", click "Manage > Add Roles and Features".




2. On the "Before you begin" page, select "Next".




3. On the "Installation Type" page, leave the defaults and select "Next".




4. On the "Server Selection" page, select "Next".




5. On the "Server Roles" page, expand "File and Storage Services (3 of 12 installed)". Expand "File and iSCSI Services (2 of 11 installed). Place a check next to "Work Folders".




6. A Features window will appear listing dependency roles and features that must be installed. Click "Add Features".




7. On the "Server Roles" page, click "Next".




8. On the "Features" page, click "Next".




9. On the "Confirmation" page, click "Install".



10. On the "Results" page, click "Close".




11. On the "Server Manager - Dashboard" select "File and Storage Services".




12. Select "Work Folders" and select the link to "create a sync share for Work Folders". (Note: You may need to click the refresh button to get the link to appear.)




13. On the "Before you begin" page, click "Next".



14. On the "Server and Path" page, scroll down and highlight "T:\Shares\IT". Click "Next".




15. On the "User Folder Structure" page, leave the defaults and click "Next".



16. On the "Sync Share Name" page, leave the defaults and click "Next".

nter the sync sh	are name	
Before You Begin	Name: IT	
Server and Path		
User Folder Structure	Description:	
Sync Share Name		
Sync Access		
Device Policies		
Confirmation		
Results		


17. On the "Sync Access" page, select "Add". Type **IT** in the name field and click "Check Names". Click "OK". Click "Next".




18. On the "Device Policies" page, click "Next".

Specify device po	olicies
Before You Begin	☐ Encrypt Work Folders
Server and Path	Automatically lock screen, and require a password
User Folder Structure	
Sync Share Name	
Sync Access	
Device Policies	
Confirmation	
Results	

19. On the "Confirmation" page, click "Create". On the "Results" page, click "Close".



20. Open a console to the WIN7 machine. Click "PC > Send CTRL+ALT+DEL".




21. Click "Switch User" and "Other User".



22. Type **mydomain\joeit** as the username and **Password1** as the password. Hit "Enter".




23. Left click the start button and select "Computer".



24. Select "Map network drive" from the navigation bar.




25. Change the drop down drive letter to T: and add the folder path \\w2k12r2-addc\IT and click "Finish".




26. The shared location will automatically open. Close the share location window.




27. Right click on the new Network Location and select "Always available offline"




28. Double click on the shared location.




29. Right click in the open white space and select "New > Text Document".




30. Name the document **Draft 1** and hit "Enter".




31. Double click "Draft 1" to open the document and type A Person Seldom Takes Naps During Parties. Click "File > Save". Close "Draft 1 – Notepad".




32. Click "Work offline" in the navigation bar.



33. Right click under "Draft 1" and create a new text document called "Draft 2".




34. Double click "Draft 2" and type **7654321**. Click "File > Save". Close "Draft 2 – Notepad".




35. Open a console to W2K12R2-ADDC. Right click the Start Button and click "File Explorer".




36. Double click the "IT (T:)" volume to open.




37. Double click on the "Shares" folder then double click on the "IT" folder. Notice that only Draft 1 has updated.



38. Return to the WIN7 machine and select "Sync > Sync offline files in this folder" from the navigation bar.




39. Return to the W2K12R2-ADDC machine to see the newly updated file.




40. On the W2K12r2-ADDC machine, right click the start button and select "Shut down or sign out > Shut down".



41. From the drop down, select "Other (Planned). Click "Continue".



42. Return to the WIN7 machine and notice that both files are still available in offline mode.



Take any screenshots and notes required by your instructor and click "I'M DONE" at the top of the topology page. You may complete this lab as many times as you wish by making a new reservation.



## 4 Research Topics (Optional)

- 1. OneDrive
- 2. Share Point
- 3. Active Directory Federation Services

## References

- Share and NTFS Permissions on a File Server
   http://technet.microsoft.com/en-us/library/cc754178.aspx
- 2. Work Folders

http://technet.microsoft.com/en-us/library/dn528861.aspx